



<http://wiki.homerecz.com>









---

- ..... 1
- ..... 1
- ..... 1
- ..... 1
- ..... 5
- Action Type** ..... 5
  - Graded Hammer Action ..... 5
  - UnGraded Hammer Action ..... 6
  - Semi-Weighed Action ..... 6
  - Spring Action ..... 6
- Keys Type** ..... 7
  - Piano Style ..... 7
  - Organ Style ..... 8
  - Synthesizer Style ..... 9
- Number of Keys** ..... 9
- ..... 10
- ..... 10
- ..... 10
- ..... 10




# Action Type

## Graded Hammer Action




G3 & G4



G3L, G4L & G5


가 . 01 ~ 88

# UnGraded Hammer Action



76 가 가

# Semi-Weighed Action




61 , 가

# Spring Action

가

# Keys Type

## Piano Style




Hammer Action key



# Organ Style

Waterfall Keys




Semi-Weighted

가






## Synthesizer Style



Spring Touch .

## Number of Keys

- 37 Keys : Monophonic Synthesizer
- 49 Keys : Monophonic Synthesizer
- 61 Keys : Organ, Polyphonic Synthesizer
- 73 Keys : Electric Piano
- 88 Keys : Acoustic Piano



<http://wiki.homerecz.com>

From:

<https://wiki.homerecz.com/> -

Last update: **2023/10/06**

: (admin@homerecz.com)