



<http://wiki.homerecz.com>

..... 1

..... 1

..... 1

..... 1

..... 5

Action Type 5

 Graded Hammer Action 5

 UnGraded Hammer Action 6

 Semi-Weighed Action 6

 Spring Action 6

Keys Type 7

 Piano Style 7

 Organ Style 8

 Synthesizer Style 9

Number of Keys 9

..... 10



..... 10

..... 10

..... 10


Action Type

Graded Hammer Action




가 . 01 ~ 88

UnGraded Hammer Action



가 .

Semi-Weighed Action



61


(Semi-Weighted) 가

Spring Action

가 .

Keys Type

Piano Style




Hammer Action key



Organ Style

Waterfall Keys




Semi-Weighted

가




Synthesizer Style



Spring Touch .

Number of Keys

- 37 Keys : Monophonic Synthesizer
- 49 Keys : Monophonic Synthesizer
- 61 Keys : Organ, Polyphonic Synthesizer
- 73 Keys : Electric Piano
- 88 Keys : Acoustic Piano



<http://wiki.homerecz.com>

From:
<https://wiki.homerecz.com/> -

Last update: **2023/10/06**

: (admin@homerecz.com)