



<http://wiki.homerecz.com>

.....	1
.....	1
.....	1
.....	1
PS22	5
PS22 spread	5
PS22 spread(10)	6
PS22 split	7
PS22 Xsplit	7
.....	9
.....	9
.....	9
.....	9

PS22



PS22 spread


PS22 , 가

가 .



PS22 spread(10)

DSP PS22 Spread Sweep 10



PS22 split

가



PS22 Xsplit

가

Stereo Out: Ins. 3 - PS22 XSplit Stereo

PS22 Full Reset

A: Default Preset | A → B | Setup A | Save

Input: 0.0 | Width: 1.00

Rotation: 0.0

Left | Right

Spread: 0.60 | Freq: 251 | Shape: 0.85 | Delay: 6.00 | X Feed: x 1.00

FCenter: 724 | FDensity: 0.00 | Tweak: 0.000 | Sweeps: 10

No Clip

-0-
-3-
-6-
-9-
-12-
-15-
-18-
-21-
-24-
-27-
-30-

-14.9 | -13.9

PS22 X-split



<http://wiki.homerecz.com>

From:

<https://wiki.homerecz.com/> -

Last update: **2024/03/13**

: (admin@homerecz.com)