



<http://wiki.homerecz.com>

..... 1

..... 1

..... 1

..... 1

..... 5

Reference 7


..... 8

..... 8

..... 8

..... 8

Crest factor, Peak factor



Peak RMS

가) 가 Peak RMS 가 18dB .(



Peak RMS

Dorrough

, Peak RMS ,

Waveform	Effective value V _{rms}	Average value V _{avg}	Conversion factor V _{rms} /V _{avg}	Reading errors for average sensing instruments	Crest factor CF
	$\frac{1}{\sqrt{2}} A$ ≈ 0.707	$\frac{2}{\pi} A$ ≈ 0.637	$\frac{\pi}{2\sqrt{2}}$ ≈ 1.111	0%	$\sqrt{2}$ ≈ 1.414
	A	A	1	$\frac{A \times 1.111 - A}{A} \times 100$ $= 11.1\%$	1
	$\frac{1}{\sqrt{3}} A$	0.5A	$\frac{2}{\sqrt{3}}$ ≈ 1.155	$\frac{0.5A \times 1.111 - \frac{A}{\sqrt{3}}}{\frac{A}{\sqrt{3}}} \times 100$ $\approx -3.8\%$	$\sqrt{3}$ ≈ 1.732
	$A\sqrt{D}$	$A \frac{f}{T}$ $= A \cdot D$	$\frac{A\sqrt{D}}{AD} = \frac{1}{\sqrt{D}}$	$\frac{(1.111\sqrt{D} - 1)}{\sqrt{AD}} \times 100\%$	$\frac{A}{\sqrt{AD}} = \frac{1}{\sqrt{D}}$


CF : Crest Factor = Peak value/RMS value

DC = 1

Sine wave = 1.414\

Reference

<https://www.izotope.com/en/learn/what-is-crest-factor.html>



<http://wiki.homerecz.com>

From:
<https://wiki.homerecz.com/> -

Last update: **2024/03/04**

: (admin@homerecz.com)