



<http://wiki.homerecz.com>



..... 1

..... 1

..... 1

..... 1

..... 5

..... 5

..... 5

(dB) ..... 5

..... 7

..... 7

..... 7

..... 7



## Amplifier

가

## Amplification Factor

=

/

( )

가

**(dB)**

(dB)

:

$$Gain(dB) = 20 \times \log_{10}(Amplification Factor)$$

10

dB

$$20 \times \log_{10}(10) = 20dB$$

100

40dB

- Gain Factor
- Current Gain
- Transconductance

- [Open-Loop Gain](#)
-



<http://wiki.homerecz.com>

From:

<https://wiki.homerecz.com/> -

Last update: **2024/12/24**

: (admin@homerecz.com)